#1671BLK & 1671BLU - RAIL RUG KIT.

#1671blk & 1671blu / Page 1 of 1

Includes:

2 - Pieces of carpet

1 - Can of contact cement

1 - Brush

Instructions:

- 1. Clean & remove all existing materials (dirt, grease, etc.) from the side rails before application of cement.
- 2. Apply the contact cement to the side rails & back of carpeting while boat is outside or in a well ventilated area. Be Cautious, read the directions on the container label.
- 3. First apply contact cement to back side of carpeting & them apply to side rails. A band of cement the width of the brush applied on the edges of carpeting is sufficient.
- 4. During application, do not get contact cement on trampoline. A good precaution would be to cover hulls & trampoline with newspaper to prevent any excess cement from dripping on the boat or tramp.
- 5. Align edge of carpeting with edge of side rail next to trampoline. Starting at stern, slowly work forward aligning carpet and edge of side rail as you go.

Do Not Stretch Carpet

6. After carpeting is lined up on top of side rail, carefully work carpeting around and under the side rail start in the middle & work towards the ends, smoothing with your hands.

www.hobiecat.com



Dealer 1 (800) HOBIE-49

#1671BLK & 1671BLU - RAIL RUG KIT.

#1671blk & 1671blu / Page 1 of 1

Includes:

2 - Pieces of carpet

1 - Can of contact cement

1 - Brush

Instructions:

- 1. Clean & remove all existing materials (dirt, grease, etc.) from the side rails before application of cement.
- Apply the contact cement to the side rails & back of carpeting while boat is outside or in a well ventilated area. Be Cautious, read the directions on the container label.
- 3. First apply contact cement to back side of carpeting & them apply to side rails. A band of cement the width of the brush applied on the edges of carpeting is sufficient.
- 4. During application, do not get contact cement on trampoline. A good precaution would be to cover hulls & trampoline with newspaper to prevent any excess cement from dripping on the boat or tramp.
- 5. Align edge of carpeting with edge of side rail next to trampoline. Starting at stern, slowly work forward aligning carpet and edge of side rail as you go.

Do Not Stretch Carpet

6. After carpeting is lined up on top of side rail, carefully work carpeting around and under the side rail start in the middle & work towards the ends, smoothing with your hands.

