

#2067 & 2068 OVERBOARD PRVENTER.

#2067 & 2068 - Page 1 of 1

Instructions

1. Secure one end of 1/8" line provided in kit to trampoline grommet nearest one end of planned preventer location.
2. Insert other end of line in blue plastic fid provided in kit.
3. Lace preventer to trampoline by inserting fid through grommet, and force fid through mesh preventer corner.
4. Hold preventer against trampoline and force fid through mesh under next grommet (on same side as first lace) and up through grommet.
5. Continue same pattern the full length of the preventer, on the same side.
6. Cross over to other side of trampoline and continue lacing back to starting point.
7. Tie off lacing at last grommet and cut and seal excess line.

www.hobiecat.com



Dealer 1 (800) HOBIE-49

#2067 & 2068 OVERBOARD PRVENTER..

#2067 & 2068 - Page 1 of 1

Instructions

1. Secure one end of 1/8" line provided in kit to trampoline grommet nearest one end of planned preventer location.
2. Insert other end of line in blue plastic fid provided in kit.
3. Lace preventer to trampoline by inserting fid through grommet, and force fid through mesh preventer corner.
4. Hold preventer against trampoline and force fid through mesh under next grommet (on same side as first lace) and up through grommet.
5. Continue same pattern the full length of the preventer, on the same side.
6. Cross over to other side of trampoline and continue lacing back to starting point.
7. Tie off lacing at last grommet and cut and seal excess line.

www.hobiecat.com



Dealer 1 (800) HOBIE-49

#2067 & 2068 OVERBOARD PRVENTER..

#2067 & 2068 - Page 1 of 1

Instructions

1. Secure one end of 1/8" line provided in kit to trampoline grommet nearest one end of planned preventer location.
2. Insert other end of line in blue plastic fid provided in kit.
3. Lace preventer to trampoline by inserting fid through grommet, and force fid through mesh preventer corner.
4. Hold preventer against trampoline and force fid through mesh under next grommet (on same side as first lace) and up through grommet.
5. Continue same pattern the full length of the preventer, on the same side.
6. Cross over to other side of trampoline and continue lacing back to starting point.
7. Tie off lacing at last grommet and cut and seal excess line.

www.hobiecat.com



Dealer 1 (800) HOBIE-49