

# #314-XXXX - UNIVERSAL BOAT / TRAMP COVER.

## Universal boat / tramp cover

Boat Covers: 314-13ALL, 314-14TO17, 314-16-GTWY, 314-17TO18, 314-19TO20

## Fitting Instructions

The Universal Boat Cover is the one inexpensive cover that will give you years of service. We recommend the full cover be used silver side up to avoid excess heat absorption. Either side is UV radiation tolerant. The tramp cover can be used black or silver side up.

### Fitting the boat cover is completed as follows:

1. Unfold the cover in an open area along side the boat.
2. Once you have figured out front, back, left and right side, position it on the boat with the mast and wires in position. (The cover can be used mast up or down, on or off a trailer. If used mast down don't attempt to cover the mast, pass the cover between the mast and trampoline.)
3. There will be points where the cover is bunched up instead of hanging over the sides. Use a scissors to cut a slit from the outer edge of the cover to the point where the part causing the bunching (wire, wing leg, etc.) is attached to the boat. Because the woven polyethylene is plastic covered, the slit will not snag, tear or stretch.
4. Apply the adhesive backed Velcro provided with the cover to the beginning of each slit, hook to one side, loop to the other. Four-inch strips are adequate length. These will reduce the flapping of the cover in the area of the slits.
5. Tie the sewn on nylon straps to secure the cover. Don't worry about tying those that run along the bottom if the boat is stored on the beach, just tuck the bottom edge under the hull.
6. Secure the tramp cover portion per 3 and 4 below.

**Installation is now complete.**

