

1. Follow rigging diagram for installation.
2. Attach the furler cleat to the front Xbar as shown in FIG. B.
3. Attach the sail cleat to the jib as shown in FIG. C.
4. To hoist the jib, attach the halyard shackle to the grommet at the head of the sail. Enclose the forestay and jib halyard line with the zipper luff as you hoist the sail. Cleat off the line in the cleat you installed on the sail.

Note - When lowering and raising your mast, position your rotater arm in the up position so it does not damage the front crossbar and furler cleat.

