

## Procedure:

1. Drill out existing rivets in tang and reinstall to dimensions shown.
2. Drill out old style FWD boom cap and reinstall new boom cap assy. Supplied.
3. Attach vertex to boom with nut and bolt supplied.
4. Replace old gooseneck with new gooseneck as shown.
5. Attach boom to mast with clevis pin and ring ding supplied.

